

VI.5.3D-OBSFUTWN PROGRAM FCST HCL TECHNIQUE OBSFUTWN

Purpose

Technique OBSFUTWN sets whether warning messages will be printed if the specified last hour of observed data does not match the contents of the Preprocessor Data Base.

Valid values are NO (0) and YES (1).

The Global default value is NO (0).

This Technique is Universal.

Form of Input

OBSFUTWN(integer)

where integer is 0 or 1 specifying whether OBSFUTWN is off or on

Example

OBSFUTWN(1)

Warning messages will be printed if the specified last hour of observed data does not match the contents of the Preprocessor Data Base.